

# CORE 1002-CM

## LTE Plug-In Modem



### CORE 1002-CM Installation Guide

1. Remove the 1002-CM and label from packaging.
2. Insert SIM(s). If only one SIM is to be used, insert this into the SIM1 position.
3. Remove the power cable from the host product.
4. Remove the blank plastic cover from side product.
5. Insert the 1002-CM into the slot and push firmly until the module clicks into place.  
Take care to align the connectors properly.
6. From the host product kit, get the replacement cover plate with antenna holes and clip this into place over the 1002-CM.
7. From the host product kit, get the two cellular antennas and screw them to the 1002-CM antenna connectors.
8. Take the supplied IMEI sticker from the 1002-CM kit and apply it to the underside of the host product.
9. Plug the power cable back into the host product and follow the installation instructions.

#### ADDITIONAL SUPPORT

[accelerated.com/support](http://accelerated.com/support)

+1 (813) 699-0295